


## PNEUMATIC TOOL PARTS LIST

■ COIL NAILER  
Model NV 38AB

1992 • 6 • 15  
(E1)



PARTS

NV 38AB2

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
1	880-191	TOP COVER	1	
2	878-115	HEX. SOCKET HD. BOLT M5X28	4	
3	880-200	EXHAUST COVER	1	
4	880-198	GASKET (A)	1	
5	880-190	HEAD VALVE SPRING	1	
6	878-800	HEAD VALVE O - RING	1	
7	880-410	HEAD VALVE (A)	1	
8	878-596	PISTON RING	1	
9	880-195	PISTON O - RING	1	
10	880-188	PISTON	1	
11	880-188	CYLINDER PACKING	1	
12	880-187	CYLINDER WASHER (A)	1	
13	988-374	O - RING (P - 32)	1	
14	881-124	CYLINDER	1	
15	880-185	PISTON BUMPER	1	
16	881-126	BODY	1	ab 04, 1999
17	880-450	WARNING LABEL	1	881127 BODY ASSY, INCL. 88, 89
18	955-478	RETAINING RING (E - TYPE) FOR D6 SHAFT	1	
19		NAME PLATE	1	
20	880-674	TRIGGER (A)	1	
21	880-194	PUSHING LEVER GUIDE	1	
22	880-181	NAIL GUIDE SHAFT	1	
23	873-093	O - RING (1AP - 3)	1	
24	880-176	ADJUSTER STOPPER	1	
25	881-120	NOZE	1	
26	949-660	HEX. SOCKET HD. BOLT M6X20 (10 PCS.)	2	
27	983-545	NEEDLE ROLLER	1	
28	949-770	ROLL PIN D4X14 (10 PCS.)	1	
29	878-132	FEEDER ARM	1	
30	878-340	FEEDER SPRING	1	
31	880-187	FEEDER	1	
32	880-204	PUSHING LEVER SPRING	1	
33	880-171	PUSHING LEVER (B)	1	
	880-383	ADJUSTER (B)	1	
35	880-175	ADJUSTER SPRING	2	
36	959-148	STEEL BALL D3.175 (10 PCS.)	2	
37	881-090	PUSHING LEVER (A)	1	
38	880-081	WASHER	1	
39	949-857	HEX. SOCKET HD. BOLT M6X12 (10 PCS.)	1	
40	881-092	NOSE CAP (A)	1	
41	302-196	MACHINE SCREW M5X20 (BLACK)	1	
42	880-183	O - RING (I.D. 37.2)	1	
43	880-379	CAP	1	
44	872-035	DUST CAP	1	
45	949-518	ROLL PIN D3X18 (10 PCS.)	1	
46	949-539	ROLL PIN D3X25 (10 PCS.)	2	
47	959-155	STEEL BALL D3.97 (10 PCS.)	1	
48	982-454	SPRING (C)	1	
49	880-088	CHANGE KNOB (B)	1	
50	877-898	HEAD VALVE O - RING (I.D. 16.8)	1	
51	878-881	VALVE BUSHING (B)	1	

\*: ALTERNATIVE PARTS

PARTS

NV 38AB2

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
52	878-885	O - RING (S - 18)	1	
53	878-925	O - RING (I.D 8.8)	2	
54	981-317	O - RING (S - 4)	1	
55	880-672	VALVE PISTON (B)	1	
56	878-887	O - RING (I.D 11)	1	
57	878-884	PLUNGER SPRING	1	
58	880-873	PLUNGER (A)	1	
59	878-888	O - RING (I.D 1.8)	1	
60	880-871	VALVE BUSHING (A)	1	
61	872-645	O - RING (P - 9)	1	
62	880-168	FEED PISTON	1	
63	873-570	O - RING (P - 18)	1	
64	880-169	FEED SPRING	1	
65	877-476	BUMPER	1	
66	880-170	FEED PISTON COVER	1	
67	983-748	RETAINING RING FOR D24 HOLE	1	
68	880-177	MAGAZINE BUSHING	1	
69	878-103	GUIDE LOCK	1	
70	880-446	SPRING	1	
71	874-436	O - RING (P - 4)	1	
72	880-162	NAIL GUIDE	1	
73	880-163	NAIL STOPPER (A)	1	
74	878-575	STOPPER SPRING	2	
75	880-164	NAIL STOPPER (B)	1	
76	880-165	NAIL GUIDE COVER	1	
77	880-201	NAIL GUIDE COVER (B)	1	
78	880-166	COVER	1	
79	878-337	SLEEVE (B)	1	
80	880-413	NYLOCK HEX. SOCKET HD. BOLT M4X10	1	
81	880-476	WARNING LABEL	1	
82	881-091	MAGAZINE	1	
83	877-371	NYLON NUT M5	1	
84	881-122	MAGAZINE COVER	1	
85	872-971	RETAINING RING (E - TYPE) FOR D3 SHAFT	1	
86	877-152	HINGE PIN	1	
87	881-121	MAGAZINE ASS'Y	1	INCLUD.82.84 - 86
88	880-408	GRIP TAPE	1	
89	880-407	TAPE	2	

\*: ALTERNATIVE PARTS

