


H06

Tanaka

THT-262


Serial No. - S088680

H06-01**THT-262 CYLINDER / PISTON / CRANK SHAFT**

REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
061	157-11666-90	1	
062	255-0630G-21	1	-J038890
063	018-00502-21	1	-R029040
063	018-00546-21	1	R029041-
064	002-01601-80	1	
065	990-11050-161	4	
066	992-10050-012	4	
067	017-01620-20	1	
068	041-01601-20	2	
070	039-00000-20	2	
071	031-01620-20	1	
072	037-01700-20	1	
076	046-0162B-81	1	
077	999-62091-345	1	
078	068-10100-20	1	

H06-02


THT-262 CRANK CASE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	990-12060-155	2	
002	798-0639W-20	1	
006	990-11050-161	4	
007	992-10050-012	4	
008	198-05015-80	1	
009	112-0162B-20	1	
016	991-01080-011	1	
017	992-10080-012	1	-L292500
018	992-00080-011	1	
019	155-21720-80	1	
026	990-11050-301	4	
027	992-10050-012	4	
028	072-0162A-91	1	
029	090-00601-20	1	
030	999-66152-500	2	
031	999-61600-200	2	
032	071-02007-20	V	
032	071-02007-21	V	
032	071-02007-22	V	
032	071-02007-23	V	
032	071-02007-24	V	
033	999-61629-000	1	

H06-03


THT-262 IGNITION COIL



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
036	990-11040-081	1	-J197456
037	992-10040-012	1	-J197456
038	159-21401-872	1	-J197456
039	173-0162R-80	1	-J197456
040	990-11050-121	1	
041	992-10050-012	1	
042-1	904-0162B-80	1	-J197456
042	904-0162B-20	1	J197457-
043	991-01060-013	1	
044	894-01401-20	1	
051	990-11040-181	2	
052	992-10040-012	2	
053	992-00040-011	2	
054-1	167-21507-80	1	-J197456
054	167-21952-80	1	J197457-
055	165-0162V-20	1	
056	992-10050-012	2	
057	990-11050-161	2	
058	178-0136M-80	1	J197457-

H06-04


THT-262 ENGINE




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
002	994-15040-142	4	
006	990-11050-601	2	-G234070
006	990-11050-651	2	G234071-
007	992-10050-012	2	
008	786-00601-20	2	
011	402-00601-20	1	
012	990-11050-221	2	
013	992-10050-012	2	
014	992-00050-011	2	
015	404-01620-21	1	
016	991-78050-010	2	
017	403-01620-20	1	
047	591-0162V-20	1	
048	675-0608A-90	1	
049	680-00731-20	1	
050	223-0162B-90	1	
051	497-32350-20	1	
052	700-03005-05	1	
056	655-06100-20	4	
057	641-0162B-20	1	
058	992-10050-012	1	
059	990-11050-101	1	
060	091-0162A-20	1	J235951-
063	595-0423Q-90	1	
086	626-32550-20	1	

H06-05


THT-262 MUFFLER




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
021	994-15050-182	1	
022	738-01620-20	1	
023	994-15050-122	3	-J235950
023	994-15050-122	2	J235951-
024	203-0630B-20	1	
026	011-0630B-20	1	
031	133-01620-22	1	
032	992-01050-011	1	
033	990-11050-101	1	
034	737-01620-20	1	
035	705-01620-91	1	
036	739-01620-21	1	
037	717-01620-81	1	
038	994-13040-122	2	
039	992-01050-061	2	
040	990-51050-453	2	
041	716-01620-21	1	
061	994-15050-122	1	-J235950
061	994-15050-162	1	J235951-

H06-06**THT-262 AIR CLEANER**


REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	410-0162B-90	1	
001	436-0162V-20	1	
002	528-0162V-20	1	
003	999-67008-012	1	
004	470-0602N-20	2	
005	423-0162B-20	1	
006	446-0162V-20	1	
007	476-04060-20	1	
008	999-67004-000	1	
009	424-0162V-21	1	
010	170-32161-20	1	

H06-07**THT-262 RECOIL STARTER**


REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	762-0162B-90	1	
001	839-00025-20	1	
002	837-06092-20	1	
003	788-06092-20	1	
004	832-06092-20	1	
005	836-06092-20	1	
006	769-01250-20	1	
007	779-01250-20	1	
008	783-0162V-20	1	
009	780-0162B-20	1	
010	772-06150-20	1	
011	785-01620-20	1	
012	795-01620-20	1	



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
000	455-25023-90	1	
001	514-25001-20	1	
002	575-25010-20	1	
003	577-25007-20	1	
004	576-25006-20	1	
005	578-25007-20	1	
006	603-25001-20	1	
007	477-25007-20	1	
008	473-25001-20	1	
009	605-25001-20	1	
010	546-25001-20	1	
011	475-25001-20	1	
012	474-25001-80	1	
013	476-25004-20	1	
014	548-25012-20	5	
015	462-25006-20	1	
016	463-25006-20	1	
017	488-25008-20	1	
018	539-25008-20	1	
019	464-25010-80	1	
020	489-25008-20	1	
021	486-25009-20	1	
022	461-25023-20	1	
023	623-25001-20	1	
024	460-25023-20	1	
025	485-25003-20	1	
026	557-25006-20	1	
027	467-25003-20	1	




REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	300-32250-80	1	
011	086-37900-20	1	-F145801
012	992-01040-011	2	-F145801
013	992-10040-012	2	-F145801
014	990-11040-121	2	-F145801
015	801-10205-20	1	
016	288-0162B-81	1	
017	999-62101-004	1	
018	277-37900-90	1	
021	307-37900-21	1	
022	101-37900-80	2	
023	068-00300-20	1	
024	100-33210-20	1	
025	158-37900-20	1	
026	016-35100-20	V	
027	303-33210-20	1	
028	999-61629-000	1	
029	301-33210-20	1	
036	060-33210-20	2	
037	176-0062W-20	1	
038	992-00050-011	4	
039	992-10050-012	4	
040	990-11050-221	4	
041	992-00040-011	5	
042	992-10040-012	5	
043	990-11040-221	5	



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
003	991-01060-011	2	-J235950
003	991-01060-011	1	J235951-
004	992-10060-012	2	-J235950
004	992-10060-012	1	J235951-
005	992-01060-011	2	-J235950
005	992-01060-011	1	J235951-
046	212-33250-20	1	-H259080
047	165-33130-20	1	
048-1	051-33210-82	1	-P249500
048	051-3318B-80	1	P249501-
051	123-33202-20	5	
052	992-10060-012	5	-P249500
052	992-01060-011	4	P249501-
053	992-01060-011	1	
054	128-33202-20	1	-P249500
054	128-37904-20	1	P249501-
055	136-3318B-20	1	P249501-
056	122-37900-20	1	
057	121-33202-20	1	-L088145
057	121-37900-21	1	L088146-
058	120-33202-20	1	-L088145
058	120-37900-21	1	L088146-
061	129-33202-20	5	
062	124-33202-21	4	
063	125-33202-20	1	
066	085-33202-20	2	
067	071-33202-20	2	
068	070-37900-20	1	
069	992-10050-012	2	
070	990-11050-121	2	
076-1	138-33215-20	1	-P249500
076	138-3318B-21	1	P249501-
080	381-37900-20	1	J235951-
081	992-01100-011	1	J235951-
082	052-37900-20	1	J235951-
085	350-33210-20	1	J136051-

H06-11 THT-262 REAR HANDLE



REF. NUMBER	PARTS NUMBER	Q'TY	SERIAL NUMBER
001	055-37900-90	1	-P249500
001	055-37904-90	1	P249501-
002	991-78040-010	6	
003	725-32600-20	1	-P249500
003	765-32120-20	1	P249501-
004	066-32300-20	1	-P249500
005	053-33222-22	1	
006	064-33225-20	1	-P249500
007	994-31030-101	1	
008	258-11650-20	1	
009	925-32530-20	1	
010	170-0162B-80	1	
011	319-37900-20	1	
012	061-32600-20	1	
013	231-33210-20	1	
014	230-33210-20	1	
015	054-33222-22	1	
016	992-00040-011	6	
017	992-10040-012	6	
018	990-11040-251	1	
019	990-11040-301	2	
020	990-11040-161	3	
026	885-37900-80	1	
027	460-33111-20	1	
028	050-33222-20	1	
031-1	778-36100-20	1	-F145801
031	164-10030-00	1	F145802-